



www.chemengonline.com

**April 2017** 

Volume 124 | no. 4

## Cover Story

36 Part 1 Batch Drying with Vacuum Contact Dryers

Drying is a demanding unit operation where solvents need to be removed without altering product chemistry. Vacuum contact dryers are essential pieces of equipment for accomplishing this task

43 Part 2 Optimizing Analysis for Spray Drying

Precise control over spray-drying processes can be enabled by modern measurement approaches that provide realtime information on particle size and shape

#### In the News

#### 9 Chementator

Algae printing ink has safety and sustainability benefits; Pilot project captures rainwater for wine production; Award to lower costs for flow-battery reactants and membranes; A quest for making ammonia at moderate conditions; and more

16 Business News

Messer opens its largest  ${\rm CO_2}$ -recovery plant; Wacker expands silicon-metal capacity at Norwegian production site; KBR awarded revamp contract for LG Chem ethylene plant expansion; World's largest MTO plant starts up in China; and more

18 Newsfront The Spread of Nitrogen Fertilizers

As price margins tighten, ammonia and urea producers are diversifying their products, while new catalysts and process improvements boost capacities and lower energy consumption

22 Newsfront The Future of Safety Sensors is Here Now

Wearable sensors enhance chemical plant worker safety and help close the approaching skills gap

#### Technical and Practical

33 Facts at your Fingertips Gas Detection

This one-page reference provides information on major classes of gas detection technologies and on the characteristics of several gases that may be targets of detection in CPI facilities

34 Technology Profile Bio-based Adipic Acid Production from Glucose This process description outlines a catalytic approach for making adipic acid from glucose

**49 Feature Report Part 1 Crossflow Membrane Filtration Essentials** Several aspects of crossflow membrane filtration, including process design, equipment selection and control, are detailed here

60 Feature Report Part 2 Gas-Phase Filtration Media

**Properties: What to Know** There are many physical properties that can impact the ultimate performance of adsorbent media in gas-phase filtration applications



## **Technology Profile**

#### **Bio-based Adipic Acid Production from Glucose**

#### By Intratec Solutions


dipic acid is one of the most commercially important aliphatic dicarboxylic acids. It is produced on a large scale primarily to supply the nylon 6,6 production chain. Other applications include the manufacture of coatings, synthetic lubricants, fibers, plastics, plasticizers and polyurethane resins.

#### The process

In the process described in the following paragraphs, adipic acid is produced from glucose via a two-step catalytic process (Figure 1).

Glucaric acid synthesis. A alucose solution is mixed with process water and heated before being fed to the oxidation reactor. Oxygen is supplied to the reaction by feeding compressed air to the bottom of the reactor. The overhead from the reactor is fed to a knock-out drum, a liquid stream is recycled to the reactor and most of the recovered gaseous material is recycled to the air compressor. The reactor's bottoms product is cooled and filtered, and glucaric acid is recovered as a solid. It is then fed to rotary dryers to remove water. Dry glucaric acid is conveyed to the hydrodeoxygenation feed mixer.

Adipic acid synthesis. Glucaric acid is dissolved in acetic acid and heated before being fed to the hydrodeoxygenation reactor. Glucaric acid reacts with hydrogen at high pressure, yielding adipic acid and water. The reactor's overhead stream, a hydrogenrich stream, is partially condensed to remove light byproducts, which are burned as fuel. The gaseous stream



Raw material Pathway Main product

FIGURE 2. Multiple production pathways exist for adipic acid

is recycled to the hydrogen compressor. The reactor's product stream is expanded in a turbo generator, producing electricity. Its low-pressure output is directed to a knock-out drum in which a hydrogen-rich gaseous phase is recovered and recycled to the hydrogen compressor and a liquid phase, composed mostly of acetic acid, water and adipic acid, is directed to a crystallizer. The output from this crude crystallizer is then filtered and fed to a rotary dryer to recover crude adipic acid. The mother liquor from the filter and the acetic acid evaporated from the dryer are mixed and fed to an extractive distillation system to remove the water content from the acetic acid so it can be recycled to the hydrodeoxygenation feed mixer. Crude adipic acid must still be dissolved in water and then subjected to further crystallization, filtering and drying to reach fiber-grade purity.

#### Adipic acid production pathways

Adipic acid production has been predominantly based on cyclohexane and, to a lesser extent, phenol.

Shifts in the hydrocarbon market and growing environmental concerns have resulted in the development of alternative production routes for adipic acid from renewable resources, such as sugar and fatty acids (Figure 2).


#### **Economic performance**

Using data from Q3 2013, variable costs (raw materials and utilities) for manufacturing fiber-grade adipic acid from glucose in the U.S. are estimated to be around \$1,100/ton of product, accounting for a significant portion of the production costs.

This column is based on "Bio-based Adipic Acid Production from Glucose – Cost Analysis," a report published by Intratec. It can be found at: www. intratec.us/analysis/adipic-acid-production-cost.

Edited by Scott Jenkins

Editor's note: The content for this column is supplied by Intratec Solutions LLC (Houston; www.intratec.us) and edited by Chemical Engineering. The analyses and models presented are prepared on the basis of publicly available and non-confidential information. The content represents the opinions of Intratec only. More information about the methodology for preparing analysis can be found, along with terms of use, at www.intratec.us/che.



- 1. Oxidation reactor
- 2. Air compressor
- 3. Rotary drier
- 4. Hydrogen compressor 5. Hydrodeoxygenation reactor
- 6. Expander
- 7. Crude adipic acid crystallization
- 8. Acetic acid recovery
- Crude adipic acid purification
   Refrigeration system
- 11. Steam boiler
- 12. Cooling tower
- CW Cooling water ST Steam RF Refrigerant

FIGURE 1. The production of bio-based adipic acid from glucose via a two-step catalytic process is shown here

# HOTOPRODUCTS

#### 3D Level Sensor Visualizes Material in Silo



Get x-ray vision!
BinMaster's 3D Scanner is the ONLY level
sensor to measure and map multiple points
and create a 3D visual of the topography of solids stored in silos.
Accounts for surface variations in lump materials, granules, powders, flakes, or pellets for accurate


inventory VOLUME of 1% to 3% of total stored volume. Models for high temperatures or with a Teflon coating for clingy materials. Multiple scanner systems for accuracy in very large vessels. MultiVison software monitors all silos with automated alerts. Minimal maintenance and works in high dust!

#### **BinMaster**

www.binmaster.com/products/info/40-3d

Circle 01 on p. 78 or go to adlinks.chemengonline.com/66427-01

# Under Pressure - how to safeguard high pressure processes



High Pressure applications require special overpressure protection due to the demanding process conditions including pressures up to several thousand bar and temperatures over

300° C which mainly occur in autoclaves. Related compressors face similar pressures.

REMBE HPRD rupture discs protect various high pressure processes around the world. They were recently approached by one of the leading multinational companies to protect their polymer plant in Belgium and help to bring them in line with European regulations on pressure equipment.

#### **REMBE GmbH Safety + Control**

www.rembe.de

Circle 02 on p. 78 or go to adlinks.chemengonline.com/66427-02

#### Dry Screw Vacuum Pumps for Solvent Handling



Customers depend on Tuthill's experts for sizing dry screw vacuum pumps used in solvent vacuum systems. Tuthill

offers the SDV series with variable pitch rotors for reduced power consumption and lower exhaust temperatures. Optional PTFE internal coating is available. The KDP series with constant pitch rotors offers simplicity and reliability, along with PFA coated internals standard. You can trust Tuthill's experience and knowledge to identify if a dry screw pump is the right choice for your application. With its environmentally friendly design and Tuthill's complete solution offering, the decision to choose Tuthill is easy.

#### **Tuthill Vacuum & Blower Systems**

https://www.tuthillvacuumblower.com/dam/2835.pdf

Circle 03 on p. 78 or go to adlinks.chemengonline.com/66427-03

#### Step up to the "Vari-Flow" Distribution Valve



Internal Guide & Support System:

The "Vari-Flow" Distribution Valve has been designed with a superior internal guide system that supports the stem and disc providing support needed to allow the valve to be used for balancing flow.

Maintenance Free Opera-

Manufactured from 304 stainless steel and UHMW plastic, which eliminates corrosion and maintenance concerns. Bushing assembly replaces easily from exterior, eliminating costly downtime.

#### Positive Shutoff:

An improved gasket system allows complete (positive) shut-off of the water stream without the persistent leaking associated with conventional valves.

#### **Vari-Flow Products**

www.industrialcoolingtowerservices.com/variflowvalve.cfm

Circle 04 on p. 78 or go to adlinks.chemengonline.com/66427-04

# Batch Drying With Vacuum Contact Dryers

Drying is a demanding unit operation where solvents need to be removed without altering product chemistry. Vacuum dryers are essential pieces of equipment for accomplishing this task

### **Eberhard Tritschler**

Ekato Systems GmbH

#### **IN BRIEF**

VACUUM DRYING

BATCH DRYING PROCESS

**EQUIPMENT OVERVIEW** 

VACUUM DRYER DESIGN

DUST FILTER

SOLVENT-RECOVERY SYSTEM

PROCESS CONTROLS

DRYING PROCESS STEPS

CONCLUDING REMARKS

rying solids is a demanding task that requires both knowledge of process technology and a sound mechanical design of the equipment used. This article provides an overview of batch-drying principles of the solid provides and provides and provides and provides of the solid provides and provid

ciples and possible options for vertical vacuum-contact dryers.

Most solids in the chemical process industries (CPI) are recovered by precipitation or crystallization. The suspended solids are mechanically separated by filtering or centrifuging in the first instance. In most solid-liquid-separation processes, thermal evaporation does not compare favorably with mechanical separation by filtration or centrifugation with respect to energy efficiency. However, when it comes to the final moisture content, thermal evaporation is often the follow-up step to mechanical dewatering methods in order to achieve the desired dryness.

The residual moisture content of the solids after filtration or centrifugation is influenced by the properties of the solid's crystal structure. A typical filtration cake can show residual moisture content of between 5 and 45%. To dry a wet cake to lower values, thermal evaporation is an effective way to achieve a true "dry" solids powder.

For some products, continuous drying processes, such as belt and conveyor drying or spray drying, are suitable methods to achieve a dry powder in a single pass. While continuous systems are not a subject of this article, more information can be found in Part 2 of this Feature Report, "Optimizing Analysis for Spray Drying Processes" (p. 43).

#### **Vacuum drying**

During any drying process, all additives and solvents have to be removed from the solid




FIGURE 1. Batch drying processes typically consist of the components and steps shown here

material without changing its original chemical composition. In essence, there must be no changes to the molecular structure during the drying process and no derivatives formed due to the drying process.

A vacuum contact dryer is built to evaporate solvents from a solid by the use of the following physical and mechanical parameters: temperature; low pressure; and mechanical fluidization by agitation.

In most cases, vacuum contact dryers are restricted by the requirement that they not influence the chemistry of the product. However, special processes are possible, where the application of high temperature will initiate or control a chemical reaction.

The degree of residual moisture in the finished product is strictly related to the use of the product and its specifications. Examples include the following: less than 5% moisture for waste material for disposal; less than 3% in foodstuffs for storage considerations; less than 1% in herbal extracts; and less than 0.1% in active pharmaceutical ingredients (APIs).

A vacuum contact dryer can achieve these values for the separation of solids from solvents and there are cases where the solids, the solvents or both, are valuable products.

#### **Batch drying process**

Almost all batch drying processes consist of the process steps mentioned in Figure 1. Whether the steps are performed in a nonagitated tray or in an agitated vessel, the con-


cepts discussed here for evaporation and re-condensing and collecting the solvents are the same.

Each process step in batch drying has individual issues that require special attention: *Filling*. During filling, factors such as the use of gravity or force (pumping), as well as the need for a contamination-free transfer into the dryer will have to be addressed.

**Mixing.** In order to create an even temperature and solvent-concentration distribution in the bulk material, as well as to support the outflow, mixing is mandatory in the dryer. However, the influence of shear forces created by the mixing action on the solids needs to be addressed.

**Re-condensing.** Whether the purpose of the drying is to retain the dry power and discard the solvent, or vice-versa, is determined by the user. Re-condensing and collection of the solvents is a demanding task in the process.

**Evaporation of free solvent.** The solvent selection dictates the evaporation conditions (enthalpy) and the maximum temperature limits of the solids dictates the thermal limitations for the drying system.



**Evaporation of bound solvent.** Some solvents tend to stick to the solid particles by physical bridging, or to hide in the pores of the particle structure, while others don't. In order to predict required process times, detailed knowledge of the separation behavior is critical.

Cooling. For safe discharge, it might be required to cool the solids to very low tem-

FIGURE 2. Vacuum drying systems require several pieces of key equipment

TABLE 1. EXAMPLES FOR IDENTIFYING PROCESS LIMITATIONS						
Product	Process	Solvent	Vacuum level	Max. temperature		
Polymers	Post treatment	Water	Med. (50 mbar abs)	High (300°C)		
Pigments/flame retardants	Vacuum drying	Water, organics	Med. (50 mbar abs)	Average (80–100°C)		
API	Post drying	Water, organics	Low (8 mbar abs)	Low (40°C)		

peratures prior to discharge. Since the heat removal from a dry power is subject to even lower heat-transfer coefficients, the cooling step might be time consuming.

**Discharge.** While fluids or suspensions drain well from a vessel, draining a dry powder can be a challenge. Residues after draining are lost in most instances and reduce the cost efficiency of the dryer.

In addition to the aforementioned basic requirements, supplemental codes and standards, such local laws, pressure vessel regulations, good manufacturing practice (GMP) rules, pharmaceutical standards, U.S. Occupational Safety and Health Administration (OSHA) requirements and explosion protection measures have to be considered.

#### **Equipment overview**

The following section is intended to identify the key components of a vacuum drying system (Figure 2).

Heat source. With respect to the heating source for the dryer, available site utilities, as well as product specifications have to be considered. While a supplier of aluminum pigments might ban water as a heating fluid for fire hazard reasons, an API producer might avoid thermal oil to avoid contamination risks. Both are secondary aspects, not directly related to the physical operation of heating.

The base specification for a dryer heating system should consider the following:

- Provide a sufficient amount of heat (Joules) in an energy efficient way
- Provide measures to keep a constant temperature in the system

The correct heating power and capacity calculation has to consider the following:

- Initial heating of all wetted components (equipment) within a reasonable amount of time
- Provide sufficient energy to heat the product load to the operating temperature
- Provide sufficient energy to evaporate the solvent load at the given conditions
- Compensate for energy losses
- Maintain temperature
   In most cases, circulating a clear fluid in

a closed loop is the appropriate method for transporting the energy from the heat source to the dryer vessel. For thermal fluids, water, water-glycol mixes or thermal oils are common.

For its high specific-heat capacity, water is the first choice as a thermal fluid when the temperature needs to stay below 150°C. At process temperatures above 150°C, thermal oil becomes more feasible, since oil shows only a marginal pressure rise at elevated temperatures.

Whether the closed loop is driven by one heat exchanger for heating and one heat exchanger for cooling, or the system is fed by a centralized plant heating and cooling system is to be decided based on the site conditions. Proper sizing is important.

Prior to any equipment selection, the physical limitations for the process need to be defined by the process owner. Each and every process has special demands, including (but not limited to) the three examples in Table 1.

#### Vacuum dryer design

The majority of commercially available vacuum contact dryers are built according to the same principle: a jacketed vessel — either horizontal or vertical — with a wall-wiping agitator. Vertically oriented dryers can take advantage of gravity to influence product flow (Figure 3). Vertical vacuum-contact dryers include the following:

- An upright cylindrical vessel with a fillingto-height diameter ratio designed for bulk mixing
- A cone bottom to support the outflow of solids
- A jacketed to suit the selected heating system
- A top-entry agitator, designed for solids applications (re-starting in settled solids)
- Valves and safety applications to operate a pressure vessel

Solids impellers circulate the entire contents of the vessel from the gravity filling until the gravity discharge. The impellers can be hydrofoil type, designed to create maximum flow with the lowest possible power input.

Energy balance is important. Mixing power by the impeller equals the power into the process. In a temperature-sensitive process, excessive mixing power input might disturb the fragile temperature balance in the product.

The key feature of all agitators in a vacuum contact dryer is an agitator system that operates with minimum wall clearances and wipes the full wetted surface of the vessel. Wall clearances from 5 to 15 mm are common and feasible, and require both a pre-

cisely fabricated vessel and a deflection-free balanced impeller.

Since the process is typically operated under vacuum, the vessel must be fabricated according to the American Society of Mechanical Engineers (ASME) Boiler and Pressure Vessel Code (BPVC), and must also follow local laws and regulations, as applicable.

#### **Dust filter**

By heating a wet solid in the closed vessel, evaporation will start. The solvents will be condensed in an external solvent-recovery system. This migration of solvents will create a strong gas flow that may cause dust formation as the solids dry.

Commercially available solvent-recovery systems are built for heavy duty services, but not for high amounts of dust. In order to prevent the plugging of lines — or simply to keep the solids where they belong, in the dryer vessel — a dust filter is installed on top of the dryer vessel.

Modern dryers feature heated filter domes with automatic blowback clean-

ing systems that are properly designed to protect the solvent-recovery system from the dust.

Two types of commercially available filter elements are discussed here, but others' experience might include many more systems.

The dust-loaded area of the dryer is separated from the solvent recovery line by a gas-tight filter plate. This filter plate carries the filter elements. One possibility is a fabric bag filter mounted on a wire cage, while the other is a sintered metal or wire mesh (10 µm) cartridge made of metal wire or metal fibers

The selection of one of these filter systems is based on owner preference and on the overall operating conditions (including temperature). While the fabric bag filters are disposable and low in replacement cost, the metal cartridge is reuseable with a high lifetime expectation.

In both cases, proper sizing of the filter is critical. An undersized filter will lead to an excess pressure drop in the solvent-recovery line, with effects on the total evaporation regime.



FIGURE 3. Vertical solids dryers can take advantage of gravitational forces for solids flow

	TABLE 2. TYPICAL EVAPORATION TEMPERATURES FOR WATER				
Water	Pressure, mbar abs	Boiling temperature, °C			
	1,013	100			
	100	45			
	10	5			

	TABLE 3. TYPICAL EVAPORATION TEMPERATURES FOR ETHANOL					
Ethanol		essure, mbar abs	Boiling temperature, °C			
	1,0	013	82			
	10	0	32			
	10	1	5			

TABLE 4. TYPICAL DRYING BEHAVIORS					
System	Step 1	Step 2	Step 3		
Pigment drying	Evaporate surface moisture	Transition	Evaporate crystal moisture bound in the capillary		
Comment	High solvent load, low dust emission	Dust emission starts	Long duration, low solvent load, dust formation		

#### Solvent-recovery system

As the vacuum contact dryer evaporates the solvents, the solvent-recovery system needs to re-condense the solvent, usually at the same rate. There are many ways to achieve this objective. This article covers one method that has shown some advantages when it comes to collecting the solvent for further use (Figure 4).

A robust vacuum pump (liquid-ring pump or dry-running pump) creates the initial low pressure that will activate the process. Design criteria for the pump includes the following:

- Evacuate the total system volume in a reasonable time
- Maintain the vacuum level under changing process conditions
- Compensate for air leakage across the full system
- Compensate for inert gas volumes introduced during the process

In essence, the vacuum pump has to keep the system running while also covering for losses.

The key component of the solvent-recovery system is the heat exchanger or condenser that is installed on the low-vacuum side of the pump. Properly designed and activated with the proper cooling fluid, solvents evaporated in the hot dryer vessel will migrate to the cold surface of the heat exchanger and will be re-condensed.

Condensation on the vacuum side of the pump will result in a huge draft — the condenser acts as a "vacuum pump." The liquefied solvents are collected in a collection vessel for further use or transfer. Cooling or

insulating the vessel is recommended when the system is installed at higher ambient temperatures.

With respect to the cooling methods, again the circulation of a clear fluid is one of the first choices. Based on commonly used solvents and the vacuum level achieved, anything from water (at 8°C) to brine (at -15°C) might be required. One item needs to be considered: water at 25°C should not be considered "cold."

Collecting the solvents is the most precise method for back-calculating the residual moisture in the dry product. This can be done simply by measuring the solvent volume. A small amount of solvents, however, might escape even a properly designed condenser. To catch the saturated solvents, a second condenser in the exhaust line of the vacuum pump might be required.

#### **Process controls**

All of the components mentioned in this article require safe and precise operation. The large number of signals to be processed and valves to be handled does not allow manual operation of such a system, except situations involving small-scale tests in a laboratory environment. Automatic process control systems that focus on a proper temperature and vacuum regime are mandatory for industrial vacuum drying.

#### **Drying process steps**

As noted earlier in the article, an effective drying process requires knowledge of the full picture of the process, including filling, mixing, re-condensing, evaporation of free solvent, evaporation of bound solvent, cooling and discharge of products

*Filling.* There are many ways of transferring a solvent-loaded wet cake into a drver vessel. This could be the subject of an article on its own, covering all aspects such as contamination, operator exposure levels, explosion risks and dosing the correct amount. Some dryers provide a wide opening at the top of the dryer vessel where valves, dosing or conveying systems, including (but not limited to) material-containment apparatus, can be installed. Gravity will support the filling process. Mixing. During the filling process, the mixer may or may not run. However, it has to be designed for re-starting in settled solids at any time during the process. Stalling during a drying process should be avoided. In some rare cases, however, stopping the agitator is even required to overcome a certain process condition. In essence, an "off-theshelf" agitator will not do the job. Dryer agi-

FIGURE 4. The solvent-recovery system recondenses the solvents as the dryer evaporates them



ing the dry solids will consume additional production time. In addition, the stainless-steel mass of the dryer equipment also needs to be cooled. In cases where time is of the essence, it might be beneficial to separate the functions and transfer the hot solids by closed pipe into a designated cooling vessel directly below the dryer. This procedure saves the energy required to cool the equipment mass.

Maximum yield after discharge is important for the cost balance of the drying system. In a single-product manufacturing process, leaving residues in the drying vessel for the next batch may be permitted. However, in a typical pharmaceutical or fine chemicals process, "cross-contamination" of products is banned.

With a cleverly designed vessel and a flexible agitator, the equipment can be made to suit the flow characteristics of the product. A vertical vessel will, by nature, drain better than a horizontal drying vessel. A cone bottom supports outflow far better than a flat or dished bottom. The agitator must be in a position to rotate at elevated speeds, including the changing the direction of rotation for discharge. Also, surface polishing and surface linings can help to reduce friction as the solid product flows.

**Scaleup.** Scaling up a drying process requires both small-scale testing capabilities and scaleup experience. Once successfully dried at a 25-, 50- or 100-L scale, scaleup rules can be used to predict the following:

- Drying time
- Solvent load, energy demand
- Residues after discharge
- Particle size changes due to shear on the product
- Wear of the agitator parts due to exposure to the product

As a basic rule, a safe scaleup requires that the geometry of the small-scale test dryer is geometrically similar to the production-size dryer.

Scaleup works best when the trials have been carried out under identical physical parameters (such as pressure and temperature) as the full-scale process. If this is not possible, correction factors have to be applied to the scaleup formula. The scaleup rules consider the following items:

- The ratio of volume-to-heated-surfacearea of the small-scale dryer to the full-scale dryer
- A temperature correction factor in moving from small scale to full scale, if

the values deviate from one another

• A factor to account for the influence of agitation speed on the evaporation If all data are available, safe scaleup by a factor of 200 is readily achievable.

#### **Concluding remarks**

The information included here describes the basic concept of a vacuum contact-drying system. This type of system can be applied to many chemical applications by designing the components accordingly. The following are some of the typical situations:

- Selection of wetted parts with respect to corrosion (most commercially available metals)
- Designing the components for GMP standards (food and pharmaceutical industries)
- Designing the components for critical solvents, such as organic solvents
- Designing the components for severe site conditions (outdoor and weather protected)
- Designing the components for high demands on cleanability (cleanroom environment)
- Designing liquid cleaning systems (clean-in-place; CIP) for the dryer vessel
- Designing the components for out-ofspecification applications (high temperatures and pressures)

Aside from plant experience and knowledge of the process, cooperation with a capable dryer company opens a wide range of possibilities beyond vacuum contact drying. Applications include solvent extraction from herbs and spices; all-in-one reaction systems for paints and pigments; food pasteurization and drying; and all-in-one chemical reactor/dryers.

Edited by Scott Jenkins

#### **Author**



Eberhard Tritschler is product manager for sales at Ekato Systems GmbH (Käppelemattweg 2, 79650 Schopfheim, Germany; Phone: +49 7622-6907-808; Email: eberhard.tritschler@ekato.com; Website: www.ekato.com). Tritschler has served in sales and application engineering at Ekato Systems since 2005, and prior to that, worked in sales and application engineering at several other Ekato

divisions. Tritschler holds a bachelor's degree in mechanical engineering from the Technical School of Engineering in Lörrach Germany, and has also earned a degree in business administration from the HWK School in Schopfheim, Germany. Aside from his day-to-day business duties in the sales organization of Ekato Systems, Tritschler also speaks at customer seminars, tradeshows and business schools. He has special expertise in the mechanical aspects of vacuum contact drying, as well as extractions and all-in-one reactions in batch-type mixing vessels.

# A small footprint takes a big step

EKATO's new lab dryers are flexible and versatile

**EXATO SYSTEMS Germany** is promoting a range of "desktop-type" laboratory-scale dryers. With working volumes of 3–61, the VPT3 dryers cater to a growing demand for drying tests in vertical apparatus, and also allow small batches of product to be manufactured. Scale-up is easy because the design matches EKATO's full-scale dryers.

The base model in this plug-and-play system is a drying vessel with a water jacket for heating or cooling. The variable-speed motor accepts both the EKATO PARAVISC impeller for free-flowing solids and the EKATO ISOPAS impeller for pasty products.

Working pressures range from -1 to +2 barg. Vacuum is provided by a membrane vacuum pump with condenser and condensate vessel. Working temperature is up to 131°C. Contact parts are made from stainless steel. with other materials available on request.

dryers handle both free-flowing and pasty materials, and are ideal for process development

**EKATO VPT3 laboratory** 

Control is

via a touch screen, with an electric motor used to lift the vessel lid. A data logger and an interface for remote data transfer are available on request.

Just like EKATO's production-scale dryers, the VPT3 dryers can handle thick pastelike products just as easily as low-viscosity suspensions. For shear-sensitive active ingredients that require gentle drying, the EKATO PARAVISC impeller combines uniform product circulation with good heat transfer. Varying the shaft speed allows experimenters to find the operating point that reliably achieves the shortest drying times or the best product properties. A rental unit is available.